

Instruction to Access Raspberry Pi

Jieliang (Rodger) Luo

April 8th, 2018

1. Join Swarm Local Network

- Password: RobotSwarm

2. Access Raspberry Pi via SSH

- Open Terminal
- Type "ssh pi@10.0.1.x"
 - Robot 0 - 10.0.1.100
 - Robot 1 - 10.0.1.101
 - Robot 2 - 10.0.1.102
 - Robot 3 - 10.0.1.103
 - Robot 4 - 10.0.1.104
 - Robot 5 - 10.0.1.105
 - Robot 6 - 10.0.1.106
 - Robot 7 - 10.0.1.107
- Password: robots1234

3. Access Raspberry Pi via File Sharing

- File -> Go -> Connect to Server
- smb://pi@10.0.1.x
- Same password